

# Thermoskan 2,1 L Thermos jug 2.1 L Thermoskanne 2,1 L Thermos 2,1 L



## **(NL) GEBRUIKSAANWIJZING**

Thermoskan 2,1 liter met hendel voor eenvoudige uitgifte



### **WAARSCHUWING**

- Voor gebruik de plastic zak verwijderen en buiten het bereik van baby's en kinderen houden ter voorkoming van verstikking.
- Niet in kinderledikanten, -wagens of box gebruiken.
- Niet geschikt voor gebruik in de buurt van kinderen. Deze kan is niet bedoeld voor gebruik door kinderen.
- Niet met warme melkproducten, vruchtensap, droog-ijs, of koolzuurhoudende dranken vullen.
- Gebruik deze kan niet in de auto. Bij heen en weer schudden kan er drank uittreden.
- Drink nooit direct uit de kan of de tuit.
- Draai de kan nooit om, de drank kan dan uitstromen.
- Plaats de kan nooit naast of in een bak- of magnetron oven.
- Draag de kan alleen aan het hengsel, niet aan de behuizing.
- Verwijder nooit onnodig de bodem.
- Plaats de hendel weer in de eerste positie, als de kan niet wordt gebruikt.

### **INGEBRUIKNAME**

De binnenfles voor gebruik met heet water ompoelen.

### **GEBRUIK**

#### **Deksel openen**

- Beweeg de draaghendel naar achteren.
- Druk de knop aan voorzijde in en kantel het deksel naar achteren.

#### **Hete dranken**

- Wanneer u de thermoskan voor een hete drank wilt gebruiken, de binnenfles 5 à 10 minuten met heet water voorverwarmen.
- Giet na het voorverwarmen de kan leeg en vul deze met de hete drank die u warm wenst te houden.
- Verwijder de mengpijp en vul tot 3 cm onder de opening.
- Plaats de mengpijp en sluit het deksel.

#### **Koffiezetten**

De thermoskan is uitgevoerd met een speciale mengpijp, waardoor het mogelijk is om direct in de kan koffie te zetten. De mengpijp zorgt voor een constante koffie kwaliteit.

- Verwarm de thermoskan voor, zoals voorgeschreven.
- Plaats de lege thermoskan goed gecentreerd onder de filteruitloop.
- Start de koffiemachine, de koffie stroomt nu direct in de thermoskan.

#### **Koffie uitdoseren**

- Sluit het deksel, deksel moet dicht klikken.
  - Til de hendel op totdat de veiligheidsklem de hendel vergrendelt.
  - Kopje onder de tuit houden en de hendel rustig indrukken.
- Let op: Als u te hard op de hendel drukt, kan de drank spuitend uit de tuit komen.

#### **Gekoelde dranken**

- Voor gebruik met koud water ompoelen
- Giet de drank in de thermoskan.
- Breek het ijs (blokjes) in kleine stukjes.
- Vul de thermoskan met ijs.

### **ONDERHOUD**

De buitenzijde van de kan reinigen met een schone vochtige doek.

Gebruik geen schuurmiddelen.

De kan niet in het water dompelen of in de vaatwasmachine reinigen.

#### **Dagelijkse reiniging**

Na gebruik de binnenfles goed ompoelen met warm water, of reinig indien nodig met Animo koffie aanslagoplosmiddel.

De stijgbuis met warm water spoelen en afdrogen.

## **(GB) MANUAL**

Thermos jug 2.1 litre with lever for easy dispensing



### **WARNING**

- Before use, keep plastic bags away from small children to avoid choking hazard.
- Do not use plastic bags in cribs, beds, carriages or play-pens.
- Do not use with or near children.
- This jug is not intended for use by children.
- Do not fill with warm milk products or baby food, fresh juice, dry ice or carbonated drinks.
- Do not carry the jug in a car. Tumbling or jolting during transport may cause sudden outflow.
- Do not drink directly from the jug or spout.
- Do not tilt or overturn the jug, the contents may flow out.
- Do not place near or inside a stove or microwave oven
- When carrying the jug, be sure not to hold the outer lid. Always use the handle.
- Do not remove the base of the jug unnecessarily.
- Be sure to put the lever back in the first stage position when not in use.

### **PREPARATIONS BEFORE USE**

Before use, rinse the inner bottle thoroughly with hot water.

### **USE**

#### **To open the lid**

- Move the handle to the back of the jug.
- Squeeze the front button and lift the lid upwards.

#### **Hot beverages**

- When using the thermos jug for hot beverages, pre-heat the inner bottle 5 à 10 minutes with hot water.
- Empty the thermos jug after pre-heating and fill it with the hot beverage.
- Remove the mixing tube and fill upto 3 cm below the mouth of the inner bottle.
- Place the mixing tube and close the lid.

#### **Making Coffee**

The thermos jug is designed with a special mixing tube, that makes it possible to brew coffee directly into the thermos jug. The mixing tube ensures a constant quality of the coffee.

- Pre-heat the thermos jug as described above.
- Centre the empty thermos jug under the filteroutlet, with open lid.
- Start the coffee machine and coffee runs directly into the thermos jug.

#### **To dispense beverages**

- Close the lid, lid has to close with a click.
  - Lift the lever arm high enough to engage the safety prop that holds it in place.
  - Hold a cup under the spout and press the lever.
- Attention: If you press the lever too hard, the contents may splash out of the spout.

#### **Cold drinks**

- For cold beverage pre-cool with cold water
- Pour the beverage into the thermos jug.
- Break the ice (cubes) into small pieces.
- Fill the thermos container with the ice.

### **MAINTENANCE**

The outside of the jug can be cleaned with a clean wet cloth. Never use any abrasives.

Do not immerse the thermos jug in water.

Do not clean the thermos jug in a dish washer.

#### **Cleaning (daily)**

Rinse inner bottle with warm water after each use, or clean with Animo coffee fur remover if necessary. Wash the stopper with luke-warm water and dry.